As for fixed installation, there are several installing methods.

1□ standing on the top of the wall

Address: ERALED Industry Park, Xincheng Road, Shajing town, Bao an District, Shenzhen, China
Email: manager@eraled.biz□ MSN: ERALEDdisplay@hotmail.com,Skype: ERALEDdisplay

2.embed into wall

Address: ERALED Industry Park, Xincheng Road, Shajing town, Bao an District, Shenzhen, China
Email: manager@eraled.biz MSN: ERALEDdisplay@hotmail.com,Skype: ERALEDdisplay

3、stick on the wall(hanging on the wall)

Address: ERALED Industry Park, Xincheng Road, Shajing town, Bao an District, Shenzhen, China
Email: manager@eraled.biz MSN: ERALEDdisplay@hotmail.com,Skype: ERALEDdisplay

4. standing on the single pillar

Address: ERALED Industry Park, Xincheng Road, Shajing town, Bao an District, Shenzhen, China
Email: manager@eraled.biz MSN: ERALEDdisplay@hotmail.com,Skype: ERALEDdisplay

www.domautomobile.ro
eraled.biz

5. standing on the two pillar

Thanks for your reading.

Address: ERALED Industry Park, Xincheng Road, Shajing town, Bao an District, Shenzhen, China
Email: manager@eraled.biz MSN: ERALEDdisplay@hotmail.com,Skype: ERALEDdisplay